



HT1053/HTH1053, Outdoor Stake Timer assembly.

1. Place collar over the threaded hole on bottom of the timer, (fig A), then screw the middle height section into the bottom of the timer.
2. Screw the pointed stake section into the middle height section of the timer, as shown in (fig B).

