

Congratulations on your purchase of a Newport Coastal 'Base Lantern'. You have purchased a safe, dependable, and easy-to-install outdoor, post lighting system. You can use this fixture at home for outdoor post lighting applications.

WHAT'S INCLUDED: A - Post Collar B - Wire Connector (3) C - 4-1/4" Fixture Mounting Screws (3) D - Fixture Lid E - Set Screw (1) F - Louvers (2)
G - Diffuser H - Nut Caps (3)
Required: Phillips Screwdriver, 3" Diameter Lamp Post, Silicon Sealant or Caulk, Drill

IMPORTANT SAFETY INFORMATION

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH ALL APPLICABLE INSTALLATION CODES.

- IF YOU ARE NOT FAMILIAR WITH ELECTRICAL WIRING, IT IS RECOMMENDED THAT YOU SECURE THE SERVICES OF A WELL QUALIFIED ELECTRICIAN WHO CAN ASSURE THAT THIS INSTALLATION MEETS LOCAL, STATE, AND NATIONAL CODES.
- BE SURE POWER IS TURNED OFF AT THE MAIN POWER PANEL OR FUSE BOX PRIOR TO INSTALLATION OR REPLACING FIXTURE.
- Before installing this fixture, be sure to check with local ordinances regarding approved outdoor lighting. This fixture style may not be allowed in some areas.
- This fixture is for outdoor use only.
- Do not install on a post or pole that results in a vertical rise of 25 feet or higher. Suitable for mounting within 4 feet of the ground.
- Apply a weatherproof silicon sealant or caulk around the fixture base after installation.
- The electrical system and the method of connecting the fixture to the system must be in accordance with local, state, and national electric codes.
- This fixture is to be connected to a 120 volt, 60 Hz power source. Connecting to a different power source may create a hazard and will void the warranty.
- This fixture is suitable for wet locations.
- Do not use near or around flammable/combustible material or liquids.
- When replacing the lamp (bulb), use only Type A medium base lamp (bulb) - 60 Watt Maximum. Never use a lamp (bulb) with a higher wattage than the stated maximum allowed on the fixture. Using a higher wattage lamp may cause a fire hazard and/or damage to the unit.
- The lamp (bulb) and fixture can get hot during use. Turn off the power and allow the fixture to cool down for at least 10 minutes prior to working on the unit.

PRIOR TO INSTALLATION - Carefully read through the entire installation instructions before installing this fixture.

WARNING: BE SURE POWER IS OFF AT MAIN POWER PANEL/FUSE BOX BEFORE INSTALLING OR REPLACING FIXTURE. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

INSTALLATION INSTRUCTIONS

BE SURE POWER IS TURNED OFF AT THE MAIN POWER PANEL OR FUSE BOX PRIOR TO INSTALLATION OR REPLACING FIXTURE.

- Remove old lighting fixture. If installing at a new location, contact a qualified electrician.
- Pull the supply wires from the lamp post. If installing new lamp post with this product, please refer to instructions included with post for proper installation procedure.
- **WIRING** - See Figure 1
 - Connect the Black wire from the base of Post Collar (A) to Black wire of the supply circuit using Wire Connector (B).
 - Connect the White wire from the base of Post Collar (A) to White wire of the supply circuit using Wire Connectors (B)
 - Connect bare fixture ground wire to ground wire from supply circuit using Wire Connectors (B).

NEVER CONNECT GROUND WIRE TO BLACK OR WHITE POWER SUPPLY WIRES.




FIGURE 1




FIGURE 2




FIGURE 3

- Position Post Collar (A) over the lamp post, carefully inserting wires into the post.
- Fasten with Set Screw (E) at hole in Post Collar (A) by a drilling 1/8" diameter pilot hole at same location (Figure 2) through post. Insert and tighten screw with Phillips screwdriver.
- Position Louvers (F) onto Post Collar (A) by inserting mounting posts on Post Collar and Louvers (F) into holes as provided - Figure 3.
- Install Type A Medium Base lamp (bulb - not included) into socket housing. Lamp wattage NOT to exceed 60 Watts. See 'Installing or Replacing Lamp' Section for installation details.
- Insert Diffuser (G) by placing open end into Post Collar (A) base.
- Place Fixture Lid (D) on top of Diffuser (G) and secure using 4-1/4" Mounting Screws (C) and Nut Caps (H). See Figure 4.




FIGURE 4

INSTALLING OR REPLACING LAMPS

- **WARNING:** Turn off the power and allow the fixture to cool down for at least 10 minutes prior to working on the unit.
- Remove Fixture Lid (D) by removing 4-1/4" mounting screws (H), then lifting off Diffuser (G).
- Install Type A Medium Base lamp (bulb - not included) into socket housing. Lamp wattage NOT to exceed 60 Watts.
- To remove existing lamp (bulb) gently twist lamp counterclockwise until it becomes free of fixture. Install new lamp (bulb) by turning clockwise. Do not over-tighten lamp (bulb).
- Re-attached Fixture Lid (D).

TROUBLESHOOTING

Does not function at all

- Make sure wall switch (if applicable) is ON and that the wiring is correct.
- Check that the circuit breaker, fuse, and main circuit breaker or main power switch are ON.
- Check other accessories (photo sensor, convenience outlet, etc.) to make sure they have been installed properly.

LIMITED WARRANTY

This product is warranted to be free from defects in material and workmanship for the life of the product. If a defect in material or workmanship occurs, call 1-800-562-5625 for instructions on how to have the defective product repaired or replaced free of charge.

LIMITATIONS

- This warranty only covers Newport Coastal assembled lighting products and is not extended to other components or equipment that is used in conjunction with the product.
- This warranty is extended to original purchaser of the product. A purchase receipt or other approved proof of purchase is required before warranty service will be rendered.
- Unauthorized service or modification to this product or any furnished component will void this warranty in its entirety.
- THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY, REPRESENTATION OR CONDITION OF MERCHANTABILITY OR THAT THE PRODUCTS ARE FIT FOR ANY PARTICULAR PURPOSE OR USE, AND SPECIFICALLY IN LIEU OF ALL SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING BUT NOT LIMITED TO ANY LOSS OF BUSINESS OR PROFITS, WHETHER OR NOT FORESEEABLE) RESULTING FROM THE USE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. Some states or provinces do not allow the exclusion of incidental or consequential damages, so the above limitation or exclusion may not apply.
- This warranty gives you specific rights, and you may also have other rights that vary from state to state.

NOT COVERED

- Failure of product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship.
- Damage caused by separately purchased replacement bulbs.
- Corrosion and discoloration of brass components.
- Reimbursement for inconvenience, installation, setup time, loss of use, or unauthorized service.

Hampton Products International Corp.
50 Icon, Foothill Ranch, California 92610-3000
Made In China
© 2008 Hampton Products International Corp.
999-60370 REVA 12/08